

MORE OF A VISUAL PERSON?
SCAN THE QR CODE FOR
HOW TO VIDEO



HOW TO APPLY PATCHES

WHAT YOU'LL NEED:



DAMP WASHCLOTH

1.



FIRST THINGS FIRST
YOU WILL PLACE YOUR
PATCH EXACTLY WHERE
YOU WANT IT.

NOTE: DON'T TAKE THE
BLACK PROTECTIVE LAYER
OFF BEFORE IRONING.

2.



YOU WILL THEN PLACE
A DAMP WASHCLOTH ON
TOP OF PATCH. ONCE
YOU HAVE DONE THAT
YOU CAN START IRONING.

NOTE: HOLD THE IRON
THERE FOR ABOUT 15-20S.
REPEAT UNTIL THE PATCH
IS GOOD TO GO.

3.



ONCE YOUR PATCH IS ON
GOOD THE LAST THING
YOU'LL NEED TO DO IS
PEEL OFF THE BLACK
PROTECTIVE LAYER.

NOTE: DON'T PEEL OFF
THE BLACK PROTECTIVE
LAYER TOO FAST.