



WALL DIAGONAL CORNER CABINET ASSEMBLY INSTRUCTIONS

TOOLS NEEDED

1. Screwdriver
2. Wood Glue for Furniture
3. Rubber hammer (optional)
4. Power Drill (optional)
5. Bar clamp (optional)

STEP 1: BOX ASSEMBLY

1. Add wood glue in the grooves on the face frame and all sides panels. Please see the pictures below.







2. Slide in the smaller sides panels (12" wide) into grooves of the face frame
See pictures below



3. Add top and bottom panels
See pictures below





(Connect side panel with top and bottom panels)

4. Connect larger side panels and screw them through predrilled holes

See pictures below







5. Slide in the back panel
Pictures below



6. Attach metal brackets with screws on the top and bottom panels and add screws through predrilled holes near the top and bottom of the back panel.

Pictures below







STEP 2: SHELF ASSEMBLY

1. Attach stainless steel shelf clips at the pre drilled holes.
Picture below



2. Place the shelf with the holes facing the bottom so they lock on the metal clips.
Picture below





CONGRATULATIONS!

YOU JUST ASSEMBLED THE WALL DIAGONAL CORNER
CABINET

For any additional information please contact our customer support at 928-288-0078 or send us an email to info@manakitchens.com