

Fitting Instructions

Adaptors using pipe inserts

Imperial & Irish Pipe Adaptor (7786 / 7787 / 7788 / 7789 / 7995 / 7996)



Remove nut from fitting and discard white split ring (unless using 1 ½" pipe). Mount nut on pipe and assemble red split ring flush with the pipe end (reuse white split ring for 1 ½" pipe).



Push the barbed end of the adaptor into the pipe until it meets the stop. Then push the plain end of the adaptor into the fitting until it meets the stop.



Screw nut tightly towards the body of the fitting. Use a PLASSON wrench for 1" pipe and above.

PlasShield Adaptor



Remove nut and grip ring from fitting and discard grey nut. Mount black nut onto the pipe and assemble grip ring flush with the pipe end (discard white grip ring and use grey grip ring if provided).



Push the barbed end of the adaptor into the pipe until it meets the stop. Then push the plain end of the adaptor into the fitting until it meets the stop.



Screw nut tightly towards the body of the fitting using a PLASSON wrench.

When used in buried applications, it may be necessary to wrap the fitting with aluminium foil tape & petrolatum tape or waterproof tape as required by your local water utility company.