























Part #	Photo	Description
941962		12mm BMW / Jaguar / Mercedes
941963		10mm BMW / Jaguar / Mercedes
941964		15mm Volvo V70 / 850 AWD [Replaced by 40201309]
40201309		15mm Volvo V70 / 850 AWD
941965		13.5mm Volvo S Series Push Lok
941979		12mm Volkswagen Passat
942029		M18 x 1.5 Cadillac Dipstick Adapter
40100018		Lexus / Toyota
40100019		Ford 6R / GM Colorado Sealed Transmission Adapter (Used with Y-Adapter included with machine)
941927		Land Rover
941928		
40100035 (Complete)		Ford Transit Connect, 250 & 350
40100053 (Adapter)		
40100038		Chevy Full Size Chevy Colorado (2015+)
40100039		Ford Explorer, Taurus, Escape, Flex, & Edge

Part #	Photo	Description
40200276		Mercedes
40200275		
40100049 (Complete)		Mercedes 230 Series
40300286 (Adapter)		
40100075		Buick Envision & Enclave (2016-17) Chevy Equinox (2013-17) GMC Acadia (2013)
40100081		Audi Q5 (2016-17)
40100085		Range Rover (All) BMW X3 (2012)
40100080		Works in place of open- end hose (#55) when using 9421635 GM Adapter
40100082		Works in place of open-end hose (#59) when using 940328, 941923, or 942169 1/2" adapters
40100083		1/8" NPT Transmission Drain Plug Adapter Ford Explorer (2012+)
40200865		Toyota/Lexus Metric Step Adapter Kit (40100077)
40200883		Step adapter also works with open-end hoses #55 & #81
40200680		"TE" Adapter Replaces open-end hose #55 when using 3/8" adapters (941925, 940329, and 941910)
40200681		"TD" Adapter Replaces open-end hose #63 when using 5/16" adapter (940334)
40100109		Ford Transit Connect Ford F-150 - F-450 (Late 2000's+)

Part #	Photo	Description
40100084		Chevy Duramax female adapter for vehicles with Allison transmission (6.0L V8 and larger) Works in place of open-end hose (#149) when using 941899 5/8" adapter
40100089		Dodge / Ford (2013+) Female Thermostat Bypass Fitting
40100108		Ford 6R80 Adapter Kit 2009-17 Ford F-150 2018+ Ford F-150 3.3L 2009+ Ford Expedition 2009+ Lincoln Navigator 2009-10 Mercury Mountaineer 2011-16 Ford Territory (SZ TCDi)[3] 2011-17 Ford Mustang V6, GT, Ecoboost(15-17) 2011+ Ford Ranger 2.2L, 3.2L 2011+ Mazda BT-50 2.2L, 3.2L 2015+ Ford Everest 2.2L, 3.2L 2015+ Ford Transit
40201172		8L90 Transmission Pan Adapter
40100119		Ford Male/Female Adapters Taurus 2008+ Explorer 2011+ Flex 2009+ Edge 2007+ Escape 2013+ Fusion 2013+ MKX 2007+ MKS 2009+ MKT 2010-11 Mercury Sable 2008-09
40100111		GM 3/8" Quick Disconnect Adapters (Can be used in applications where 942163S is typically used)
40200864		Dodge 1/2 Ton FWD Truck 2017

Part #	Photo	Description
40100127		Toyota Tundra Kit (Adapter only: #40201306)
40100128		Toyota Highlander Kit (Adapter only: #40201307)
40100129		Toyota Corolla 2014+ Kit (Adapter only: #40201308)
40100146		Mazda SKYACTIV 2013+ Inline Adapter Kit
40100148		Full-Size GM Allison 1000 Series Transmission Adapter
40100151		Jeep/Chrysler Transmission Adapter
40100153		Jeep/Chrysler GC 6-Speed Transmission Adapters
40100167		Volkswagen Tiguan Transmission Adapters