

Toyota Tundra Front Plate

Be sure to use lubrication on all stainless steel nuts & bolts to prevent galling. This install is to be done at your own risk. Plates may have sharp edges and care is to be used while installing. Install can be done with the Talons Garage cat plate installed but is easier to do before cat plate installation.



- 1. Remove factory front skid plate and braces. Loosen tow hooks leaving front bolt in place and removing the rear bolts. Save bolts.
- 2. Install front skid plate bracket to the 3 M8 threaded holes on the engine cross member. Leave bracket loose to allow for alignment.
- Install Engine plate adaptor to frame. If you have a talons garage transmission skid plate this adaptor will sandwich in between the frame, and transmission skid plate.
- 4. Install front skid plate. Front of skid plate will slide under the factory tow hooks. Rear of skid plate will install to mount with M12 allen head bolts. Bumper tabs can sandwich between frame and skid plate to hold them in place.



Toyota Tundra Front Plate



- 5. Install engine skid plate. Front of engine skid plate will mount to bracket with M12 allen head bolts. Rear of plate will install with M12 allen head bolts to adaptor plate.
- 6. Go back and adjust alignment as desires and tighten all bolts.
 Oil mount and door can also be installed at this time.