

## 2<sup>nd</sup> Gen Tundra Engine Skid Plate Install Guide



1. Remove factory front skid plate and braces. Loosen tow hooks leaving front bolt in place and removing the rear bolts. Save bolts.



2. Install front skid plate bracket to the 3 M8 threaded holes on the engine cross member. Leave bracket loose to allow for alignment.

## 2<sup>nd</sup> Gen Tundra Engine Skid Plate Install Guide



3. Install front skid plate. Front of skid plate will slide under the factory tow hooks. Rear of skid plate will install to mount with M12 Allen head bolts. Bumper tabs can sandwich between frame and skid plate to hold them in place.



4. Install engine skid plate. Front of engine skid plate will mount to bracket with M12 Allen head bolts. Rear of plate will install with 3/8 x 4" Allen head bolts to TRD nut plate.
5. Go back and adjust alignment as desires and tighten all bolts. Oil mount and door can also be installed at this time.

Enjoy your new protection. Be sure to take a photo to share on your favorite social media platform or on your favorite forum. We love seeing our products in the wild and it typically makes our day!

Thank you for supporting Talons Garage,  
Shaun and Crystal