

)		hole o	f front cover	8			Dimmable wir			
		LEF	) Linear		GND AC	terminal	LED Driver	ב		•
AC wire and	e cover ough the hole of t dimmable wire go er hole of LED line	through a liste	ed conduit and pa	ass	8.Connect L, N, correspondingly. of LED linear. Do	Than fix the	conduit and t	ne side cover	r hole	
		LED Linear					LED Linear			
	LED linear just as h bracket A well.	shown above	to make bracke	et B	10.The install	ation is finish	ed.			
ow LED Lin	ear Mounting	Space and :	Steps							
			<sup>2mm</sup>	<u>1141mm</u>		42mm				
				<u>1141mm</u>	een two drilling		linear			
				Distance betw		holes in row				
1.Drill d Tap the	1141mm	the ceiling as	s shown above a hole.	Distance betw and the holes s	hould match wi	holes in row th M6-M8 se	f-tapping scr			
1.Drill d Tap the	1141mm	the ceiling as	s shown above a hole.	Distance betw and the holes s	hould match wi	holes in row th M6-M8 se	f-tapping scr			
1.Drill d Tap the 3.Let K/	1141mm	the ceiling as on tube into tube into the ceiling as on tube into tube intube into tube intube into tube into tube into tube int	s shown above a hole.	Distance betw and the holes s acket A and inse Ceili	hould match wi	holes in row th M6-M8 se expansion t racket B	f-tapping scr	ew.		
1.Drill d Tap the 3.Let K/	1141mm	the ceiling as on tube into tube intube into tube intube into tube into tube into tube int	s shown above a hole.	Distance betw and the holes s acket A and inse Ceili	hould match wi	holes in row th M6-M8 se expansion t racket B	f-tapping scr			

Г

