



**BCUSTOM
DESIGN®**

-1 DEEPLY CLEAN THE SURFACE WITH ALCOHOL.

-2 WARM THE PRODUCT SLIGHTLY WITH A PHON

-3 REMOVE THE WHITE PAPER FROM THE PRODUCT AND WARM THE GLUE SLIGHTLY.

-4 APPLY THE BADGE AND HOLD FOR AT LEAST 30 SECONDS.

-5 DO NOT TOUCH AND WASH THE BADGES FOR AT LEAST 24 HOURS AFTER APPLICATION.

-6 IF YOU SEE THAT THE BADGES DO NOT STICK SUFFICIENTLY AND HAVE NOT CAREFULLY CLEANED THE SURFACE, TRY TO APPLY THEM AGAIN BY HEATING THEM AGAIN.

IF YOU ARE UNSURE CONTACT US FOR MORE INFORMATION!