

# COMLINK RTX

IN-HELMET HEADSET



WWW.PCIRACERADIOS.COM

800-869-5636

## INSTRUCTIONS

This in helmet headset is intended for a closed face or motorcycle style helmet. Open Face helmets require a longer flex boom to reach your mouth. This headset may be exchanged for the open face style headset, or you can send in your helmets for installation for an additional charge.

**Step 1:** Determine where you will mount the microphone boom. We recommend mounting microphone booms on the left side of all helmets. Put the helmet on, place the boom in the helmet and touch the mic to your lips. Mark the placement for the microphone boom. **IMPORTANT: Make sure the protruding end of the microphone is facing your mouth.**

**Step 2:** Using hot melt craft glue, glue down the microphone boom to the inside of the helmet, preferably underneath the cheek pad. Do not cover up cheek pad buttons.

**Step 3:** Put the helmet on your head again and determine where you need the speakers to be placed so they are directly over your ears. Unpeel 3M sticker covering of the speaker, and place speakers in helmet. Some helmets have open spaces in this exact area, making for an easy install. Large amounts of padding directly over your ears may require some customization and creativity. Too much foam in between your ears and speakers will not allow sound to penetrate. We recommend no more than 1/4" of foam.

**Step 4:** Use hot glue to secure wiring junction into helmet, below the closest attached speaker to secure headset wiring within the helmet. Tuck the extra wiring in between the shell and liner. Some helmets may require a small channel cut with an exacto knife to allow room for the wire junction.

**Step 5:** If the wires are not held down tightly by the liner, use a small amount of hot glue to affix the wires to the shell. Less is more in this step. Massive amounts of glue will cause the pads to protrude. Reinstall cheek pads.

This is a noise canceling microphone. Always have the mic touching your lips or it will cancel out your voice! Always remind your passengers to "kiss the mic."

For more pictures, videos, installation tips and tricks, visit our help page at [www.pciraceradios.com](http://www.pciraceradios.com) and click on FAQ's.

# COMLINK RTX

## IN-HELMET HEADSET



EXTRA  
WIRING

JUNCTION

SPEAKER

MIC BOOM

MICROPHONE

H2NO PLUG  
WIRE



PROTRUDING END OF MIC FACES YOUR MOUTH