

## BRACKET INSTALLATION INSTRUCTIONS

### TOOLS YOU WILL NEED:

- Torx T-25 Socket
- 1/4" Drill Bit & Drill
- Silver Marker
- 7/16" Wrench
- 5/32" Allen Wrench

- 1.) Remove Dry/Storage Box
- 2.) Place the Radio and Intercom bracket where the dry box was, mark the 4 holes using the silver sharpie.
- 3.) Drill 4 marked holes.
- 4.) Remove the bracket and install the intercom into the bracket using the intercom hardware.
- 5.) Install the Radio into the bracket using the radio hardware.
- 6.) Remove Right T25 bolt from steering guard.
- 7.) Install Connector Mount to the steering guard using the same bolt you removed in Step 6.
- 8.) Finish installing connector mount into the dash by drilling the hole in the dash and using supplied hardware to mount.
- 9.) Connect the intercom to the radio. Connect all Push to talk, headset/helmet, audio input and power cables before putting the bracket into the vehicle. *(it is difficult to reach the cables once installed.)*
- 10.) Place bracket with components into position.
- 11.) Install the supplied nuts and bolts into the bracket and connector mount.

