



STEP BY STEP INSTALLATION INSTRUCTIONS

Upper & Lower Door Bags

**Polaris RZR XP Turbo/Turbo S/XP 1000
S 900 Factory Front Doors**

Upper Door Bags

Part #3001008

Lower Door Bags

Part #3001009

Visit our YouTube
channel for detailed
installation instructions



Required Tools

- ¼" Ratchet
- T40 Torx
- T25 Torx
- Bolt hole alignment tool (punch, small screwdriver, etc.)
- Flat head screwdriver
- Thread adhesive (Loctite or similar)

Install Time

Approximately 30 minutes

Note: We recommend installing the lower door bags FIRST if you have both.

Lower Door Bag Installation

(Repeat the below steps for both lower doors)



Upper Door Bag Installation (Repeat the below steps for both upper doors)



Upper Door Bag Installation (Cont'd)

(Repeat the below steps for both upper doors)



Installation of the Hypertech Powersports lower & upper door bags is complete. Now get out there and hit the trail!

Contact Info

Hypertech Tech Department

Phone: 901.382.8888

Fax: 901.373.5290

techsupport@hypertech.com

Office Hours: Monday-Friday, 8am-5pm Central Time

hypertech.com

Hypertech

7375 Adrienne Place

Bartlett, Tennessee 38133

hypertech.com