



Quick Start-Up Tips

FROGPRODUCTS.COM | 800.222.0169



Download the **FREE**
FROG Water Care® App



2 Test the water with FROG® @ease® Test Strips and balance according to the Water Balance Guidelines.

Water Balance Guidelines

Total Alkalinity..... 80 - 120 ppm
pH..... 7.2 - 7.8
Total Hardness..... 150 - 250 ppm

PLUS, a convenient
Out Indicator reading
for SmartChlor®.



3 Shock the hot tub with FROG® Jump Start® to achieve a start-up level of chlorine.



1

If previously using bromine or biguanides, drain, rinse and refill the hot tub. Otherwise proceed to Step 2.

4

Adjust the blue FROG @ease Mineral Cartridge to Setting #6. Snap into the top section of the In-Line Holder.



Reduces chlorine use up to 75*



5

Adjust the silver FROG @ease SmartChlor Cartridge per the Setting Chart.

FROG @ease Setting Chart

Gallons	Setting #
200-250	1
251-300	2
301-450	3
451-600	4



6

Snap the FROG @ease SmartChlor Cartridge into the bottom opening of the holder. Insert holder into built-in system pushing down and turning to lock. Then replace the cap.



7

Test weekly with FROG @ease Test Strips. When the SmartChlor "Out Indicator", the top color block on the test strip, is lighter than the "Out Indicator" color block on the bottle, replace the silver SmartChlor Cartridge.



Please recycle, if possible.



8

Shock the hot tub with FROG Maintain® once a month, or when replacing your SmartChlor Cartridge.

