



Installation and Troubleshooting Guide



NOTE: This installation is to be completed by an Authorized Dealer or Professional Service Technician. For questions regarding installation or warranty, call CDI Tech Support at 866-423-4832. **Do not return to the Dealer or Distributor where the part was purchased. Contact CDI Electronics Directly for Return Material Authorization.**

CDI P/N 413-9901 Wiring Harness 3 Cyl.

This harness will replace P/N: 382640.

WARNING! This product is designed to be installed by a professional marine mechanic. CDI Electronics cannot be held liable for injury or damage resulting from improper installation, abuse, neglect or misuse of this product.

INSTALLATION

1. Disconnect battery.
2. Remove original wiring harness. Be sure to make note of wire routing.
3. With old wiring harness removed clean all connection points to verify good connection of new wiring harness.
4. Install new wiring harness in the same position as original wiring harness.
5. Connect the new wire harness to the boat side harness (SERVICE NOTE: Remove the locator tab on the new harness connector in order to connect it to the boat side harness. The original connector with the locator pin to one side has not been available for over 20 years).
6. Verify proper placement of all wires. Reconnect battery.
7. Wire color chart.
 - A) **Red**- Battery cable side of starter solenoid, splits out to the Rectifier and Vacuum Switch.
 - B) **White**- Switched power to starter solenoid and Neutral Safety Switch.
 - C) **Black**- Engine Ground wire.
 - D) **Grey**- Connects to the Power Pack.
 - E) **Red/White**- Choke solenoid.
 - F) **Violet/Yellow**- To Thermo Switch and Choke Solenoid.
 - G) **Violet**- Key-On 12V to the Vacuum Switch and the Amplifier (Power Pack).
 - H) **Tan** - Temperature Sensor located on the cylinder head.
 - I) **Green**- Forward Gear Solenoid.
 - J) **Blue**- Reverse Gear Solenoid.
 - K) **Purple/Green**-Diode and Lead Assembly on terminal strip.

Wire Cross Reference

<u>Old Wire Color</u>	<u>New Wire Color</u>
GREEN	Red
Red/Yellow	Violet/Yellow
Red	Violet

NOTE: This installation is to be completed by an Authorized Dealer or Professional Service Technician. For questions regarding installation or warranty, call CDI Tech Support at 866-423-4832. **Do not return to the Dealer or Distributor where the part was purchased. Contact CDI Electronics Directly for Return Material Authorization.**

