

2016 Polaris Axys Silencer Install

- Remove Hood, Side Panels.
- Remove Factory Exhaust Springs from OEM muffler. Also remove spring from factory pipe. Use picture for reference.



- Remove and rotate Factory muffler support brace. Install with the pin facing down. See Picture.



- Remove rubber bumper from factory muffler and install it into the new silencer. See photo.



- Install new muffler on sled, position the donut gasket so its properly seated in the new silencer. Also align the outlet so it exits out the belly pan.



- Using the OEM Springs, spring the Muffler to the support bracket, than muffler to silencer, and last spring the factory pipe back down to chassis.