



## **2016+ RZR XPT Big Turbo Water Lines**

---

Please follow these instructions to connect the water lines to your new turbocharger.

1. Remove the factory hose from the water pump housing to the oil cooler. You will not reuse this hose with the new turbocharger.
2. Connect 1 new coolant hose from the water pump housing to the turbocharger. It doesn't matter which fitting you connect to on the turbocharger.
3. Connect 1 new coolant hose from the oil cooler to the turbocharger.
4. Make sure the bleed the coolant system after the installation of the new turbocharger.
5. We suggest unhooking the ignition coils and turning the starter over until oil is primed to the new turbocharger. Its best to loosen the oil inlet fitting on the turbocharger to verify oil flow.
6. After heat cycling the turbocharger please check all fittings for leaks, and tighten all the bolts.

