

AIRDROP

SILENCER

CHAINSTAY PROTECTOR KIT



AIRDROPBIKES.COM

Installation Instructions

1. Remove the rear wheel, chain, and any cable clips attached to the drive-side chainstay.
2. Clean the chainstay, making sure all mud, oil and debris are removed, then dry thoroughly.
3. Using the isopropyl wipe provided, de-contaminate the surface of the chainstay.
4. To ensure you're familiar with the process & fit, do a trial installation before removing the paper adhesive coverings.
5. Remove the paper adhesive coverings.
6. Carefully place the Silencer in its intended position, ensuring the cable boss lines up with the hole.
7. If you are not happy with the position, carefully lift the Silencer to reposition (it won't slide).
8. When you are happy with the position, apply pressure to ensure good adhesion.

Repeat steps 2-8 to install the seatstay patch.