

TAH17-SM-R14



Installation Manual

Installation

1. Using the templates provided align the edges with the features of the mirror as shown in figure 1 below. (Template size/shape and part number may vary.)



Figure 1

Installation Manual

2. Drill one ½" hole for routing the wires and two 7/64" pilot holes for the mounting screws where shown on the template.
3. Secure the lamp and the bracket to the mirror housing using the 6-32 x 1.5" screws provided.



Figure 2