

The Windrestrictor® installation only requires light mechanical skills. Stainless Steel black powdercoated brackets (included) are snapped onto the frame of the vehicle underneath the carpet, and then bolted onto the seat belt column using a specially-designed anchor system that allows for a drill-free application. Once these frame brackets are securely in place, the Windrestrictor is then mounted to the new structure using our special mounting arms and hardware shown below. This design allows for full seat travel and full top movement without removing the unit. A complete installation guide and step-by-step video will come with your order.

