

slowly cut with a sharp paper knife.

DEKORNIK zapytaj@dekornik.pl / +48 728 122 888



BEFORE APPLYING OUR WALLPAPER, PLEASE READ THESE 6 POINTS BELOW:

Non-woven paper
(on which we print wallpapers)
it is not self-adhesive
and for installation you should use
wallpaper glue - a special wallpaper
glue with a backing non-woven fab
ric. You can buy in every DIY store.
We recommend

the already mixed ones with the consistency of cream and not powder.



Please carefully **prime the wall** and clean the surface from dust or grease.

Wallpapers can be applied on the walls only

after approx. 21 days

from the last painting,
otherwise the glue will not be
as strong as it should
and the wallpaper can get peel off
or fold slightly.



Before applying the wallpaper, check that it is not damaged and there are no other

visible defects.

Please spread the strips on a flat surface - e.g. on the floor and see if the pattern fits and whether the colors are just as beautiful on each lane. 50cm

We print wallpapers in strips 50 or 100 cm wide

(depending on design), and they perfectly match themselves. Just apply one strip next to the other, with a tangent line (strips do not overlap on yourself).

100cm

And please remember
- colors on monitors
or smartphones differ a little bit from
those printed.

Each display is calibrated differently,
has a different brightness
and saturation scale.

We know our wallpapers
are printed in the most beautiful
color scale possible!