

Thank you for choosing the Pro-Spec Easy Tag Base Mount for your ride. The Base Mount is a multi-utility product, designed to elevate protection for your bike by adding protection to your existing tank and engine guards.

Please follow the instruction carefully to ensure the desired benefit of the Base Mount.

1. Loosen all the Allen head screws using a 3mm Allen key. Take apart the two halves of the Base Mount.
2. Place the suitable sleeves according to the combination chart below on both the halves of the base mount and clamp the base mount to the Engine/tank guard.
3. Ensure that the inner tabs are placed on the same side of the Base Mount.
4. Place all the Allen Head screws back and tighten it with the Allen key provided.



Sl.	DESCRIPTION	QTY.
1	Base Mount Body	1
2	4X30 Allen Cap Screws	4
3	Rubber Sleeves	
	• ET 41619	3
	• ET 42225	4

Sleeve Compatibility Chart:

16 mm → 2 sleeves of 16mm
 19 mm → 1 sleeve of 16mm + 1 sleeve of 22mm
 22 mm → 2 sleeves of 22mm
 25 mm → 2 sleeves of 25mm

Note: Though the Easy Tag Base Mount retrofits are designed for DIY installation it is recommended you have them installed by a technician if you face difficulty.

No. 5C-501 George Court,
 5th C Main Road, HRBR Layout 2nd Block,
 Bengaluru-560043.
 Karnataka, INDIA.
 +919620484111

