

# MOUNTING INSTRUCTION – EASY BRAKE 550

PS IM 06

Thank you for choosing the Pro-Spec Easy Brake for your ride. Easy Brake for the BMW G310 GS has been designed to offer convenient braking experience for everyday riding while using riding boots or leisure footwear during short & long commutes. The Standing Assist provides convenient braking support when the riders choose to stand and ride.

Please follow the instruction carefully to ensure the desired benefit of the Easy Brake.

1. Insert the base lock into the triangular footrest slot.
2. Place the Easy Brake assembly and tighten the Allen bolt.



Sl.	DESCRIPTION	QTY.
1	Easy Brake comfort base with standing assist.	1
2	Base Lock	1
3	4x16 Allen head SS bolt	2
4	4x20 Allen head SS bolt	1
5	Allen key 3mm	1



*We advise the brake pedal to be always kept at a lower level with reference to the footrest to avoid unintentional engagement of the rear brake.*

*Note: Though the Easy Brake retrofits are designed for DIY installation it is recommended you have them installed by a technician if you face difficulty.*

No. 5C-501 George Court,  
5<sup>th</sup> C Main Road, HRBR Layout 2<sup>nd</sup> Block,  
Bengaluru-560043.  
Karnataka, INDIA.  
+919620484111



V1.0