

Thank you for choosing the Pro-Spec Easy Tag Highway Footrest (22 mm) for your bike. The Easy Tag Highway Footrest has been designed to offer maximum comfort and leisure riding on open highways. The footrest will be mounted on the engine guard. Placing your boot on the footrest will reduce the strain on the rider's body giving a comfortable riding posture.

Please follow the instructions carefully to ensure the desired benefit of the Easy Tag Highway Footrest.

1. Loosen the Nyloc nut and remove the 6mm Allen bolt. Remove the rubber footrest from the setup.
2. Disassemble the U clamp by loosening the 3/8<sup>th</sup> inch Allen bolt using the 6 mm Allen Key.
3. Disassemble the base mount by loosening both the hexagonal screws with the help of a 12 mm spanner.
4. Position the two halves carefully with the silicon sleeves in place on the Engine Guard and secure back both the hexagonal screws.
5. Re-install the U clamp back on the base mount and fasten it back.
6. Slide the footrest into the U clamp and **ENSURE THE HOLES MATCH BY EXERCERTING FORCE IN THE DIRECTION AS SHOWN.**
7. Insert the 6mm Allen bolt, place the 6mm flat washer and ensure to tighten the Nyloc nut firmly.



Sl.	DESCRIPTION	QTY.
1	Easy Tag Base Mount Casted (22 mm)	2
2	U Clamp	2
3	Rubber Footrest with frame and washer	2
4	3/8 <sup>th</sup> inch Allen Cap with washer	2
5	6x35 Allen bolt with washer	2
6	NYLOCK nut with washer (6mm)	2
7	Thread locker 243 0.5 ml	1

**Note:**

Though the Easy Tag Highway Footrest retrofits are designed for DIY installation, it is recommended you have them installed by a technician if you face difficulty.

Please ensure to apply the thread locker on the 8X12 Allen Cap Screw before threading it in the Aluminium Mount. This will ensure that the threads do not loosen out due to vibrations.



No. 5C-501 George Court,  
5<sup>th</sup> C Main Road, HRBR Layout 2<sup>nd</sup> Block,  
Bengaluru-560043.  
Karnataka, INDIA.  
+919620484111

