

# How to Apply Your Wallpaper

## **1. Clean your wall.**

We recommend wiping down your wall with a solution of water and isopropyl alcohol. The solution should be 30% water and 70% alcohol. Make sure it's dry before continuing.

## **2. Apply the first strip of wallpaper to the top of your wall.**

Stick the wallpaper to the top of your wall and peel the backing down about 6 inches. Use a squeegee tool and start to smooth the wallpaper out.

## **3. Each of our wallpapers will have a .5 inch overlap.**

Every wallpaper that we produce has a one-inch overlap. Before sticking your wallpaper we suggest that you line up your patterns and secure it using masking tape. This will help you always keep your pattern lined up and your wallpaper looking good!

## **4. Continue applying your wallpaper.**

Continue following the steps of lining up your wallpaper overlap and removing 6 inches of the backing. Smooth onto the wall and repeat the removal of the backing until you are done.

## **5. Cut the excess wallpaper off and check for Bubbles**

Once you have completed it is time to make the wallpaper look nice! Make sure to cut along the baseboards of your wall and along the ceiling. This will remove any excess wallpaper. Look for any imperfections such as bubbles under the wallpaper. (To remove bubbles make a slight pin prick in the wallpaper and smooth over the spot)

## **6. You're Done! Enjoy.**

*Thank you!*