

**Instructions for Prima Lance Cali/Havana Cowl Protectors**  
**SKU# 0200-0214**

**Tools Needed:**

10mm socket

6mm hex

4mm hex



**Product and Hardware**



**Step 1: Remove plug and unscrew rear floorboard screws as well as rear body screws.**



**Step 2: Put on "optional" rubber sleeve if you choose to**



**Step 3:** Hand tighten rear bolts with washers.



**Step 4:** Put on “optional” rubber sleeve if you chose to use it and connect the two bars.



**Step 5:** Insert spacers in each rear floorboard screw locations



**Step 6:** Hand tighten 2nd pair of long screws to the long portion of the 90 degree bracket. Hand tighten short pair of screws that thread into bracket on the bars.



**Step 7: Fully tighten all hardware and enjoy!**