



Wallpaper Glue No. 389

Use: For the glueing of light, medium-heavy and heavy wallpapers.

Preparation: Substrate must be firm, dry and clean. Fill cracks and holes with AURO Wall Filler No. 329. Crumbling plaster can be solidified with AURO Primer for Various Plaster No. 301. Pre-paste highly absorbent substrates.

Application: Stir powder evenly, avoiding clumps, into cold water. Let it swell for one hour and stir well again. Paste the rear of the wallpaper evenly, let soak and paste on. Apply glue especially thoroughly at the seams.

Composition: Methyl cellulose

Processing	Mixing ratio suffice approx.:	Water per 200g	200g for
Pre-pasting	1 : 80	16 Litres	120 – 160 m ²
Light wallpapers	1 : 50	10 Litres	80 – 100 m ²
Medium heavy wallpaper	1 : 45	9 Litres	60 – 80 m ²
Heavy wallpapers, raw fibre papers	1 : 40	8 Litres	40 – 60 m ²

Attention: Store dry and cool and keep out of reach of children. Do not pour into the sewage. Dry remenants can be composted or put into the household garbage. Disposal of liquid residues: EAK waste code 200112; EAK classification: paints, glues.