

Custom Vanity Countertop Installation Guide

Congratulations on your custom vanity countertop!

Follow these step-by-step instructions to install it seamlessly onto your brand-new cabinets:

Before You Begin:

1. Gather Supplies:

- Custom vanity countertop with pre-made sink cutouts, faucet holes, and 4" backsplashes
- Adhesive for sink (included with the countertop)
- Waterproof and paintable caulk
- Level
- Safety equipment (gloves, goggles, dust mask)

2. Prepare the Area:

- Ensure that your custom brand-new cabinets are installed securely and level.

Installation Steps:

1. Adhere the Sink:

- Locate the markings underneath the countertop indicating where the sink should be placed.
- Apply the adhesive provided onto the marked areas.
- Position the sinks onto the adhesive according to the markings.
- Press down firmly to ensure a secure bond.
- Allow the adhesive to dry completely as per the manufacturer's instructions.

1. Position the Vanity Top:

- Carefully place the custom vanity countertop onto the brand-new cabinets, ensuring it aligns properly with the edges.
- Use a level to check for evenness and adjust the cabinets if necessary.

3. Install the Backsplashes:

- Apply a bead of waterproof and paintable caulk along the back of each backsplash.
- Position the backsplashes onto the back wall ensuring they align with the edges of the countertop.
- Press them firmly into place.

4. Caulk and Seal:

- Apply a bead of caulk along the edges of the countertop where it meets the cabinets.
- Also, apply caulk along the seams where the backsplashes meet the wall.
- Smooth the caulk with a damp finger or caulk tool for a clean finish.
- Allow the caulk to dry completely as per the manufacturer's instructions.

5. Final Checks:

- Double-check the vanity top and backsplashes for any gaps or unevenness.
- Make any final adjustments as needed.

Maintenance Tips:

- Follow the care and maintenance plan provided by your countertop supplier to ensure its longevity and beauty.
- Regularly clean the countertops with a mild soap and water solution to remove any dirt or residue.
- Avoid harsh chemicals or abrasive cleaners that may damage the surface.

By following these steps and maintenance tips, you can successfully install your custom vanity countertop onto your brand-new cabinets. Enjoy your beautiful new addition to your bathroom!