



# INSTALLATION INSTRUCTIONS FOR 1995-2004 TOYOTA TACOMA TAILGATE TABLE, KITS AP-311086, AP-311087, AP-311114 AP-311115, AP-311118, AP-311119

	<b>NOTICE</b> Read instructions completely before installing this product. Refer back to the instructions frequently during installation.		<b>CAUTION</b> Flying Object Hazard. Fluid Splash Hazard. Wear safety glasses at all times when working on vehicle.
--	----------------------------------------------------------------------------------------------------------------------------------------------	--	------------------------------------------------------------------------------------------------------------------------------

	<b>WARNING:</b> Cancer and Reproductive Harm - <a href="http://www.P65Warnings.ca.gov">www.P65Warnings.ca.gov</a>
--	-------------------------------------------------------------------------------------------------------------------



1. Remove the (8) screws holding the access panel to the tailgate. These screws will not be reused. **NOTE:** Do not remove the access panel after you remove the screws.



## AP-311131



**2.** Place the All-Pro Tailgate Table onto the tailgate and align the mounting holes in the table with the holes in the tailgate.



**3.** Install the supplied (8) washers and (8) Pozi drive screws to secure the tailgate table to the tailgate. Installing the screws may be easier if you initially start all the screw, then tighten them. Be careful not to over tighten the screws and strip the plastic nuts in the tailgate.



**4.** Installation finished.

