






## AP-309911 (INSTALLATION INSTRUCTIONS FOR 05+ TACOMA AND 00-06/22+ TUNDRA TAILGATE TABLE)

	<p><b>NOTICE</b></p> <p>Read instructions completely before installing this product. Refer back to the instructions frequently during installation.</p>		<p><b>CAUTION</b></p> <p>Flying Object Hazard. Fluid Splash Hazard.</p> <p>Wear safety glasses at all times when working on vehicle.</p>
<p> <b>WARNING:</b> Cancer and Reproductive Harm - <a href="http://www.P65Warnings.ca.gov">www.P65Warnings.ca.gov</a></p>			



**AP-309911**



1. Remove the screws holding the plastic panel to the tailgate. Remove the plastic panel.



2. Place the All-Pro Tailgate Table onto the tailgate and align the mounting holes in the table with the holes in the tailgate. On some models, you need to slip the lip of the Tailgate Table under the plastic tailgate cover as shown.



3. Reinstall the screws you initially removed to secure the tailgate table to the tailgate. Installing the screws may be easier if you initially start all the screws, then tighten them. Be careful not to over tighten the screws and strip the plastic nuts in the tailgate.

