

How to install the Kovea Scout Stove on an Adventure Skottle Grill

Step 1: Place the Adventure Skottle pan upside down with the leg socket up.

Step 2: Place the stainless steel bracket with the feet down and insert two front legs of the bracket into ring pockets or slots of the Skottle pan. Leave the back leg outside of the pocket for now.

Step 3: Place the Kovea stove inside the bracket with the igniter facing the opening of the bracket.

Step 4: Using one or two fingers, pull the bracket leg out a little bit and push it down and into the pocket or slot of the pan.

The stove should be securely attached to the bottom of the pan.



Step 1 & 2



Step 3



Step 4