

## Snorkel Upgrade INSTALLATION GUIDE



### **Sy-Klone Series 9001 Air Precleaner** *For Gas Motors Under 4.8 Liters*

#### **How to install:**

1. Remove the current head from your snorkel.
2. Measure the inlet after the snorkel head is removed (most cases your inlet will be 2 ½ inches, 3, inches or 4 inches).
3. Put your old snorkel head back on for the time being.
4. Order your pre-cleaner snorkel upgrade.
5. Once you have your pre-cleaner remove your old snorkel head.
6. Insert rubber adapter.
7. Place pre-cleaner on the inlet of your snorkel.
8. Tighten down the metal clamp.
9. ***Go out on your next off-road adventure knowing you don't need to worry about rain, heavy dust, snow, and other debris you might find yourself in.***