

# AJT DESIGN SHIFT KNOB INSTALLATION INSTRUCTIONS

## Step 1:

Remove existing shift knob by turning counter clockwise.

## Step 2:

Install supplied jam nut onto shaft, almost to the bottom of shaft threads.

## Step 3:

Install a second supplied jam nut onto shaft, snug against first jam nut, DO NOT OVERTIGHTEN.

## Step 4:

Install new AJT DESIGN shift knob onto shaft by hand. Turn until it stops on the top jam nut.

## Step 5:

Note position of new AJT DESIGN shift knob logo or shift pattern. Remove AJT DESIGN SHIFT knob.

## Step 6:

Adjust position of top jam nut to compensate for the position error of the shift knob in Step 5.

## Step 7:

Hold top jam nut steady and tighten bottom nut against it, DO NOT OVERTIGHTEN.

## Step 8:

Install new AJT DESIGN shift knob onto shaft by hand. Turn until it stops in on the top jam nut. HAND TIGHTEN ONLY.

## Step 9:

Repeat steps 6-8 as needed, until shift knob position is satisfactory.

### Additional Instructions for 2016+ Tacoma:

1. Remove the chrome ring at the top of the boot.
2. Zip tie the boot to the shifter rod.
3. The shift knob will cover the zip tie when installed.



### Recommended tools:

- 2 adjustable wrenches or 2 open/box end wrenches
- 13 mm hex nut – M8
- 19 mm hex nut – M12

### Notes:

- Installation process is the same for all knob types.
- Automatic gearshift knobs use an M8 x 1.25 thread
- Manual gearshift knobs use an M12 x 1.25 thread
- All transfer case knobs use an M12 x 1.25 thread

Questions?

Email: [adam@ajtdesign-llc.com](mailto:adam@ajtdesign-llc.com)

**AJT  
DESIGN**  
[www.ajtdesign-llc.com](http://www.ajtdesign-llc.com)