

How to Install

Materials Needed:

1 pegboard (provided) 1 French cleat (provided) 2 drywall screws (provided)

1 pencil 2 screws (provided)

View our video installation at https://app.plantaire.com/tutorials or scan our QR code.



Step 1:

Use a level and mark an X on the wall with a pencil for each hole on the bracket.



Step 2:

Put in drywall screws first. Then screw the French cleat with the screws onto the wall.



Step 3:

Screw the mounting bar and feet onto the pegboard then hang the pegboard mounting bar onto the French cleat.



9 plantaire

Step 4:

Hook on the cubbies onto the pegboard, wherever you please.



Step 5:

Place the cubby inserts into the cubbies. Tada! Grow cubbies.



Step 6:

Hook the 1, S shaped hook wherever you please, and hang your scissors onto the hook.



Now it's time to grow!



plantaire.

How to Grow:

Step 1:

Place seed bed into grate insert.



Step 2:

Pour water into side opening until it reaches the bottom of the seed bed. (The water simply needs to touch the jute. The jute will wick the water quickly, so no need to water above the level of the seed bed.)



Step 3:

Cover the grow cubby with its lid for the germination period. Each type of seed has its own germination period (about 4 days).



Step 4:

Once the seeds have reached their germination period, uncover the grow cubby, add additional water, and let your microgreens grow until they mature. (Usually 3-4 more days.).

Step 5:

Use your scissors to harvest!



Happy Growing



Storing Seeds and Lids

Seeds:

Hook the extra grow cubby that does not have a grow insert, and store your seeds.

Lids:

Grab the 2 "S" shaped hooks. Hook them on the very top of the back of the peg board. Hook one on the far right and one on the far left. Then place your lids into the hooks behind the peg board.

Thank you so much for being a part of our Growing Community;)

Additional Seed Packets can be purchased at PlantAire.com

