



www.b-quiet.com

B-Quiet Hliner application instructions

1. Use a knife or scissors to cut **Hliner** to the required size before removing the backing to expose the adhesive.
2. Thoroughly clean the surface to ensure it's free of moisture, dust, oil/grease or other foreign materials.
3. Remove the paper backing to expose the adhesive
4. Bend **Hliner** slightly and attach it to the panel. Slowly apply inch by inch until it's completely attached
5. Go over the entire surface of **Hliner** and ensure that it's been firmly pressed into place

©2000-2014 StereoTypes. All rights reserved



www.b-quiet.com

B-Quiet Hliner application instructions

1. Use a knife or scissors to cut **Hliner** to the required size before removing the backing to expose the adhesive.
2. Thoroughly clean the surface to ensure it's free of moisture, dust, oil/grease or other foreign materials.
3. Remove the paper backing to expose the adhesive
4. Bend **Hliner** slightly and attach it to the panel. Slowly apply inch by inch until it's completely attached
5. Go over the entire surface of **Hliner** and ensure that it's been firmly pressed into place

©2000-2014 StereoTypes. All rights reserved