



www.b-quiet.com

B-Quiet Vcomp application instructions

1. Always apply the foam side of **Vcomp** towards the source of the noise
2. Use a knife or scissors to cut **Vcomp** to the required size
3. If applying to anything other than the floor of a vehicle, a spray adhesive will be needed to secure the **Vcomp** to the panel. Follow the directions on the spray adhesive can for best results.
4. Press **Vcomp** firmly into place
5. For optimum noise reduction, use in conjunction with one of our damping products (the damping material should be installed first, followed by **Vcomp** over top)

©2000-2014 StereoTypes. All rights reserved



www.b-quiet.com

B-Quiet Vcomp application instructions

1. Always apply the foam side of **Vcomp** towards the source of the noise
2. Use a knife or scissors to cut **Vcomp** to the required size
3. If applying to anything other than the floor of a vehicle, a spray adhesive will be needed to secure the **Vcomp** to the panel. Follow the directions on the spray adhesive can for best results.
4. Press **Vcomp** firmly into place
5. For optimum noise reduction, use in conjunction with one of our damping products (the damping material should be installed first, followed by **Vcomp** over top)

©2000-2014 StereoTypes. All rights reserved