

FLAT TOP®

SAIC T60 AUTOMATIC Hard Lid Installation Instructions



Remove sports bars and place on cushioned surface



Remove bolts and discard



Open fittings Sleeve



Sports bar brackets



Fit brackets supplied
(25mm x 8mm) and spacer
washers to sports bar legs



Remount feet with spacer
washers under infill moulding



Put infills over sports bar legs by angling the infills as in picture



Replace sports bars and mount support bracket



Mount hinges on lid, put on vehicle, centre and mark female hinge position. Mount hinges with self tapping bolts thru liner.

Push down on hinge and liner while fixing.



Remove male lid hinge and assemble (lubricate pins) replace lid and re attach.



Attach pre-assembled closed strut to lid and lay back to mount on tub edge



Attach support bracket and drill mount bottom support bolt. Attach thru tub with nyloc nut



Insert stabiliser bolt and tighten



Feed wire thru tub use grommet to protect wire thru the hole

Feed wire thru chassis on driver's side

With a bit plastic blue tongue attached to wire come out near the underside of the driver's seat



Come up attach grommet and under sill cover -follow harness to kick panel



Remove rubber door seal and kick panel, attach control module to inside of panel feed power wire across underneath Instrument panel and go thru the firewall to the battery



Mount isolator switch on kick panel and leave 5A safety fuse accessible. Attach to battery with separate 10 Amp fuse



Pierce grommet and feed wire thru fire wall



Use conduit on wire anywhere under the bonnet, use cable ties to secure

