

# **URETHANE BAND SAW TIRES**

## **INSTALLATION INSTRUCTIONS for URETHANE FLAT TIRES**

**Follow these simple instructions for installation of your new tires:**

- ◆ Remove your old tires. Clean the band saw wheel of all glue and debris.
- ◆ Submerge the tires in a pot of hot water (140° F). Remove the pot from heat.  
**USE CAUTION - HOT WATER MAY SCALD YOU.** *Do not overheat the water*, incorrect water temperature will not allow the tires to return to their original size once they are cool.
- ◆ Add a small amount of dish detergent to the water. This will act as a lubricant when mounting the tires to the wheels.
- ◆ Using gloves, remove the tires from the water.
- ◆ Mount the tires immediately while the tires are still warm. You may need help sliding them in place.
- ◆ Let the tires cool completely (approximately half an hour). The wheels are now ready to be used.