

How to install Battery Locking Kit Model # SSWL

The kit contains the following parts:

1 pc 14" Cable with Mounting Screw CwMS-2

1 pc Allen Wrench AL10

The Smartlite® Battery Locking kit is a tamper proof locking system to secure the Sentinel™ Candle.

Install batteries and turn bottom cover fastener until the candle lights. Align any of the locking holes with the **arrow** on Sentinel™ Candle bottom cover. Insert the screw into the hole facing the **arrow**.

Tighten the screw with the furnished **allen-wrench**. Do not over tighten. Additionally you should place any memorial item into the viewable Memorial Chamber before attaching to securing device.

If using Ground Anchor:

Thread the **Cable** through the holes of the **Ground Anchor** and secure the loop end with padlock (not supplied)

Place the **Allen Wrench** in a safe place. You will need it again when changing batteries.