



## Rowan Engineering

### Adjustable Turret Cap for Falcon X50 Scope

Thank you for your purchase. Please read these fitting instructions before attempting to fit the Turret.

Your kit should contain -

- 1 x Inner turret, Brass Sleeve, M4x12 cap bolt.
- 1 x Outer cap.
- 1 x 1.5mm allen key.
- 1 x 2.0mm allen key.
- 1 x 3.0mm allen key.

### Safety first.

Observe safe practices when handling your rifle and follow the manufacturers safety instructions when doing so. Working on any air rifle can be dangerous. Seek advice where and when necessary.

### Fitting.

Before removing the original turret cap, turn the turret so it is in the centre of its travel. ( Normally 2 turns from the end of travel.

Loosen the central Torx screw and lift off the original turret .



Fit the brass bush to the top of the turret spigot with M4 x12 bolt and lightly tighten ensuring the slot aligns and engages with the turret flats.



Fit the inner turret over the brass sleeve and gently tighten the 3 grub screws.



Finally fit the outer cap over the inner turret and gently tighten the 3 x M4 grub screws. If a small adjustment to zero is required, simply loosen the 3 x M4 grub screws, set zero and tighten back in position.

