



UV DTF Application Instructions

1

Clean Your Surface

Start with a squeaky-clean surface. Wipe it down with isopropyl alcohol and a lint-free cloth, then let it dry. If there's oil, dust, or even a smudge left behind, the adhesive won't grab.

2

Prepare the Transfer

Flip the decal over and slowly peel away the white paper backing. The design should stay on the clear sheet. If a piece doesn't lift, lay the backing back down, rub that area, and try again.

3

Position The Decal

Line it up on your item exactly where you want it. UV DTF is sticky—take your time. (If you're nervous, the soap + water hack below gives you a little wiggle room.)

4

Press it Down

Use a squeegee or a credit card and rub firmly across the entire design. Start in the center and push outward to work out air and make sure every edge is sealed.

5

Peel the Film

Slowly peel back the clear sheet, keeping it low and steady. The design should stay behind, glossy and slightly raised. If an edge lifts, lay the film back down, squeegee that spot again, and re-peel.

Pro Tip: Mist the surface lightly with soapy water before you position the decal. This lets you slide it into place. Once it's lined up, squeegee the liquid out and let it dry overnight before peeling the film.



Got bubbles??

Squeegee firmly working from the center out – or pop with a small pin and smooth flat.