

Metal Chimney Pot Installation Instructions

- 1. The Chimney Pot is packaged with the Stainless Steel Dura Chimney Pot Adapter mounted inside the chimney pot. Although the adapter is removable if necessary, no additional assembly is required.
- Before the Chimney Pot is installed, it is recommended a storm collar be used to seal the gap between the chase top collar and the Dura Chimney Outer Wall. (The Storm collar may need to be trimmed to fit inside the chimney pot).



WARNING SHARP EDGES Watch your fingers.





Metal Chimney Pot Installation Instructions (Cont.)

3. As the Chimney pot is placed on the chimney top, the Stainless Steel Chimney Pot Adapter will fit/slide inside the Inner Wall of the Dura Chimney Flue system. (The Outer Wall of the Dura Chimney Flue System is recommended to extend 3" minimum above the chase top flashing collar).





Metal Chimney Pot Installation Instructions (Cont.)

- 4. Plumb and Level the Chimney Pot before mounting. A minimum of 8 Fasteners (a Minimum of 2 fasteners per side) are required when fastening the chimney pot to the chimney top.
 - a. All penetrations to the chimney top must be sealed with a weatherproof caulking or sealant to prevent any water intrusion into the chimney structure. Fasteners should be driven through the Chimney Pot Mounting flanges, through the chase top flashing, and into the chimney structure or framing below.
 - b. To avoid any "sagging" or "puddling" on the chase top flashing, it is recommended to consider adding additional structural support below the chase top flashing to support the weight of the chimney pot.

Rev. 2-2019



