FANBACK SERIES ASSEMBLY INSTRUCTIONS

#81 Cupholder



(717) 354-8998 • (877) 560-5966 New Holland, PA



Tools Required

- Hammer
- #2 Square Head Bit
- Power Drill
- 7/16" Socket or 7/16 wrench

Included Hardware

A 2 1 5/8" Screws

Instructions:

- Unpack items from box(es). Be sure to match any numbers & letters that you may find on the pieces.
- The cupholder can be attached where ever you'd like to have it. Attach with 2 (A) 1 5/8" Screws. (Illustration 1)



Illustration 1