ASSEMBLY INSTRUCTIONS FOR 10 & 12 ACORN GARDEN BRIDGE & ORIENTAL GARDEN BRIDGE

TOOLS NEEDED PARTS LIST HARDWARE

Ratchet Bridge (1) 5/16X3" Bolts (16)
1/2" Socket Bridge boards (4) 5/16" Nuts (16)
Screwgun Low rail boards (2) 2" Screws (32)
Post (8) Sq. drive bit (1)

- Step 1 Lay out and identify all parts and pieces. Remove low rail boards as fastened for shipping.
- Step 2 Fasten (4) post on each side of bridge at predrilled holes with (2) 5/16x3" bolts and nuts at each post.
- Step 3 Fasten low rail board on top of post with (1) 2" screw at each post.
- Step 4 Now place bridge boards where they belong according to notches and fasten with (6) 2" screws in each board.

