

(717) 354-8998 • (877) 560-5966 New Holland, PA

#166 Dining Bench 6' long



Tools Required

- Hammer
- #2 Square Head Bit
- #2 Square Drive6" Extension
- Power Drill

6' Bench Hardware

Α	1	16 2" Screws
В		18 1½" Screws

Instructions:

- Unpack items from box(es). Be sure to match any numbers & letters that you may find on the pieces.
- Lay the seat of the bench upside down on a flat surface. Following the markings, place the legs in position. Fasten each leg using 6 (B) 1 1/2" screws. Repeat on each leg. (Illustration 1)
- 3. Then following the markings on the legs, using the pre-drilled holes on the brace (Illustration 2) fasten using 4 (A) 2" screws. Repeat on the other side of the brace. (Illustration 3)
- 4. Repeat for all other braces.(Illustration 4)







