

ENGLISH GARDEN
ASSEMBLY INSTRUCTIONS



#220C,B English Garden Side Chair
 Counter Height/Bar Height

(717) 354-8998 • (877) 560-5966
 New Holland, PA



Tools Required

- Hammer
- #2 Square Head Bit
- Power Drill
- 7/16" Socket or 7/16 wrench

Included Hardware

A		2 1 1/2" Screws
B		18 2" Screws
C		8 2 1/2" Screws

Instructions:

1. Unpack items from box(es). Be sure to match any numbers & letters that you may find on the pieces.
2. To begin, lay the leg/back combo on a flat surface. Line the seat up with the lines drawn on the leg/back combo. Fasten using 2 (B) 2" Screws. Repeat on the other side of the seat. (Illustration 1).
3. After fastening the seat, fasten the two leg braces to the leg/back combo lining them up with the lines drawn on the legs. Using the pre-drilled holes on the brace, fasten using 1 (B) 2" Screw on each brace. (Illustration 2)
4. Next place the front legs in place, using the pre-drilled holes on the seat, fasten using 2 (B) 2" Screws on each side. (Illustration 3)
5. Then fasten the legs to the braces, using 2 (B) 2" screws on each brace. Fasten where the brace falls; do not force. (Illustration 4)
6. To fasten the front step, with the pocket holes facing outward (rounded edge to the back), line up the brace with the marks and fasten the foot brace using two 2 (B) 2" screws. Repeat on other side. (Illustration 5)
7. Placing the step on the brace and fasten the step in the brace using 4 (C) 2 1/2" Screws (Illustration 6) and then the brace into the step with 4 (C) Screws. (Illustration 7)
8. To finish, fasten the last front seat slat, using 2 (A) 1 1/2" screws on each side. (Illustration 8)

