ENGLISH GARDEN ASSEMBLY INSTRUCTIONS

#221C,B English Garden Arm Chair

Counter Height/Bar Height



Tools Required

- Hammer
- #2 Square Head Bit
- Power Drill
- 7/16" Socket or 7/16 wrench

Included Hardware



Instructions:

- 1. Follow instructions on the opposite side to assemble the chair.
- Fasten the arm to the back of the chair using 1 (A) 2" Screw. (Illustration 1)
- Holding the leg of the arm flush with the seat (Illustration 2), fasten with 2 (B) 2½" Screws using the pilot holes under the seat. (Illustration 3)
- 4. Repeat on the other side.



(717) 354-8998 • (877) 560-5966 New Holland, PA





