

Assembly Instructions

44" Square Walk-in Table



Thank you for choosing *A[&]L* Furniture Co.

We hope that this piece brings you many years of enjoyment!

For help with assembling your furniture, or if you have missing hardware, please email us at help@aandlfurniture.com or call us at 866-896-5747

PARTS (included)	HARDWARE (included)
A Table Top (2)	2¾ Wafer Head Bolts (4)
B 2"x2"x35" Strips (2)	2" Screws (75)
\bigcirc Table Leg Assemblies (2)	Allen Wrench (1)
D Bench Tops (4)	Square Drive Bit (1)
(E) $1^{*}x5\frac{1}{2}^{*}x14\frac{1}{2}^{*}$ Bench Leg Supports (8)	TOOLS NEEDED
\mathbf{F} 1"x5½"x32" Bench Bottoms (4)	Power drill or screwdriver

STEP 1

Lay the table tops upside down & bolt together. Insert two $2\frac{3}{4}$ " bolts in the predrilled holes in one side, two $2\frac{3}{4}$ " bolts in the other side & turn into the threaded inserts with the Allen Wrench. (See photo 1.) Now, at-tach the 2x2x35" strips, use six 2" screws in each strip. Turn into the predrilled holes and screw down into the table top. (See photo 2.)







STEP 2

Assemble the 4 bench legs. Take two leg supports and attach to a bench bottom. Put two 2" screws in the predrilled holes in each end of the bench bottom and screw into one end of the leg supports. (See photo 3.)



STEP 3

Unfold a table leg assembly & place upside down on a table. (See photo 4.) Take a bench top & place upside down with the center 2x2 between the 2x4 table leg support beams. Attach with two 2" screws on each side. (See photos 4 and 5.)

STEP 4

Now take the bench leg assemblies in Step 2 and place them on the seat. Center with the 2x2 on the bench top. Attach with two 2" screws on each end. (See photos 6 & 7.)



STEP 5

Fold the center leg down and attach to the bench bottom. Put one 2" screw in the predrilled hole in the center of the bench bottom and screw up into the leg. (See photo 8.) Now put the 2 base assemblies together and fasten with four 2" screws. (See photo 9.)



STEP 6

Place the table top on the base and latch down into the 4 corners between the 2x2 braces. (See photo 10.) Put one 2" screw into each 2x2 and screw into the top of the legs. (See photo 11.)





photo 10

photo 11