

Assembly Instructions For The Poly Swivel Barchair

<u>Tools Needed For Assembly</u>	<u>Parts List</u>	<u>Hardware</u>
5/32"Hex Wrench (included)	Seat&Leg Assembly	1/4" Bolts (10)
	Back Assembly (1)	Hex Wrench
	Right Armrest (1)	
	Left Armrest (1)	

Step 1 Unpack all parts and pieces.

Step 2 Set the seat & leg assembly on the floor. Align the predrilled holes on the back of the seat assembly with the threaded inserts on the bottom of the back assembly. Take four $\frac{1}{4}$ "bolts and put them through the holes in the seat and turn into the threaded inserts. **Note:Do not fully tighten until the arms are attached.**

Step 3 Take an armrest and align the predrilled hole on the side of the seat with the threaded insert in the brace beneath the armrest. Take a $\frac{1}{4}$ "bolt and turn in through the seat into the threaded inserts in the brace.

Step 4 Now align the predrilled hole on the back of the arm with the threaded insert on the side of the back assembly. Take a $\frac{1}{4}$ "bolt and turn in through the arm into the threaded insert Repeat on the opposite side and tighten all bolts securely with the hex wrench.

Congratulations! You now have a chair that will give you many years of enjoyment!

