

Assembly Instructions For The Hickory Rocker

Tools Needed:

Screwgun
Phillips Head Bit

Parts List

Seat Assembly (1)
Back Assembly (1)
Left Arm & Leg Assembly (1)
Right Arm & Leg Assembly (1)
Rockers (2)
Back Leg Brace (1)

Hardware

1-1/2" Silver Phillips Head Screws (4)
2" Wood Screws (2)
1-1/2" Wood Screws (10)
1-1/4" Wood Screws (6)
1" Wood Screws (4)

- Step 1** Lay out and identify all the parts and pieces.
- Step 2** Lay the arm & leg assemblies on their back on a flat surface with the front of the arms facing up. Notice there is a right & a left. Now take the seat assembly & locate the four predrilled holes on the back seat support brace. Line them up with the four predrilled holes on the back rocker legs. Fasten with four 1-1/2" screws. **Note: Make sure the front slat on the seat lays on top of the front legs before tightening. Do not overtighten any screws.**
- Step 3** Line up the predrilled holes on the front seat slat with the predrilled holes on the front legs. Fasten with four 1" screws. **Do not overtighten as this will split the wood.**
- Step 4** Find the predrilled holes on the side of the front legs and insert a 2" screw on each side fastening the front legs to the seat assembly. Now find the predrilled holes on the side of the back legs and use two 1-1/2" screws to fasten to the seat assembly.
- Step 5** Now flip the chair over so that it rests on the front seat slat. Find the two predrilled holes on the back of the back legs below the seat and attach the back leg brace with two 1-1/2" screws. Now find the 2 short braces that are attached to the front legs beneath the seat and turn them so the predrilled holes line up with the predrilled holes on the seat support brace. Attach with two 1-1/4" screws. **Do not overtighten.**
- Step 6** Set the chair upright and attach the back assembly. The top back support strip is fastened to the back of the legs and the center support strip is fastened to the front of the legs and goes between the arms. Line up the top back support strip with the predrilled holes on the back legs and fasten with two 1-1/2" screws. Now line up the holes on the bottom of the back assembly with the holes on the back of the seat and attach with two 1-1/4" screws. Next take two 1-1/4" screws and attach the middle support strip to the front of the back legs in the predrilled holes.
- Step 7** Fasten the rockers to the chair by lining up the predrilled holes in the rockers with the predrilled holes on the side of the legs and attach with the four 1-1/2" silver phillips head screws. **Note: The legs can be pulled to the proper position to line up with the holes in the rockers if needed.**

