



Required Tools:

- Tape Measure
- Cordless Drill
- #2 Square Drive bit

Hardware:

- (16) 2 1/2" Screws
- (8) 2" Screws

Parts:

- A = (1) Seat
- B = (4) Chair Legs
- C = (4) Braces

Step 1

On a smooth surface, lay the seat (A) upside down with cleats facing upward. Place the legs (B) into the pockets, with the rounded edges facing up (see inset), and attach them with (16) 2 1/2" screws, 4 screws per leg.



Step 2

Measuring down from the top of the legs 11 1/4", place the braces between the legs, as shown, and fasten with (2) 2" screws, one on each side, per leg.



Step 3

Your barstool is complete.

Thank you for purchasing from Wildridge.