

Assembly Instructions

LCC-202 Classic Swing

Required Tools:

- Hammer
- 7/16" Wrench or Socket
- 1/2" Wrench or Socket

Hardware:

- Swing Chains
- (6) 1/4" x 2" Bolts
- (6) 1/4" Flange Nuts
- (2) 5/16" x 5 3/4" Eye Bolts
- (4) 5/16" Flange Nuts
- (2) 5/16" x 5" Eye Bolts
- (4) 5/16" Washers
- (4) 1/4" x 3 1/2" Bolts
- (4) 5/16" Lock Nuts
- (4) 1/4" Washers
- (4) Connecting Links
- (4) 1/4" Locknuts



Step 1

Position back (A) and seat (B) as shown and fasten with (6) 2" bolts & nuts.

Step 2

Attach arm assembly (C) as shown with (2) 3 1/2" bolts, washers and lock nuts in seat. Thread a 5/16" flange nut on all eye bolts as far as thread allows with flange away from eye. Now use 5 3/4" eye bolts to fasten back of arm to the back. Tighten with 5/16" washer and locknut. Use 5" eye bolt for front of arm through hole provided and fasten with 5/16" washers and locknuts.



Step 3

Attach chain to eye bolt with 4 connecting links.

Complete

WILDRIDGE[®]
PURVEYORS OF QUALITY POLY FURNITURE

www.wildridge.com

330-893-4212